



Sharp LC-37SB24U Television CCFL Replacement

This video guide demonstrates disassembling the entire system to replace a lamp (CCFL). Also shown are removing the inverter, power supply and main board.

Written By: Steve Baker



INTRODUCTION

This video guide demonstrates disassembling the entire system to replace a lamp (CCFL). Also shown are removing the inverter, power supply and main board.

Always disconnect the power several minutes prior to working on a television to avoid risk of shock. Also use caution with CCFLs, they contain mercury.

This unit shuts off the screen after 2 seconds when a lamp failure is detected.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-09 06:42:50 AM.